



**HS-510TL**  
**DUAL TRIP AMPLIFIER WITH ISOLATED**  
**RE-TRANSMITTED OUTPUT**  
**FOR USE WITH LM35 10mV/°C TEMPERATURE**  
**SENSORS**

Whilst every effort has been taken to ensure the accuracy of this document, we accept no responsibility for damage, injury, loss or expense resulting from errors or omissions, and reserve the right of amendment without notice.

This document may not be reproduced in any way without the prior written permission of the company.

Hansford Sensors Ltd. June 2009

**CONTENTS**

<b>1. QUICK START GUIDE</b>	<b>3</b>
1.1 Display	3
1.2 Relays & LEDs	3
1.3 Alarm Levels Settings	3
1.4 Alarm Delays	3
1.5 Alarm Latching	3
1.6 Re-Transmit Output	3
1.7 HS-100 Connection	3
<b>2. RE-CONFIGURING THE HS-510</b>	<b>6</b>
2.1 Set Point Menu	6
2.2 Main Menu	6
2.3 Menu 3 & 4 - RELAY1 & RELAY2	7
2.4 Menu 5 & 6 - LED 1 & LED 2	8
2.5 Menu 7 & 8 - OUTPUT SPAN & OUTPUT ZERO	8
2.6 Menu 9 - INPUT UNITS	9
2.7 Menu 10 - RELAY TEST	9
2.8 Menu 11 & 12 - INPUT SPAN & INPUT ZERO	9
2.9 Menu 13 & 14 - HYS1 & HYS2	9
2.10 Menu 15 - OUTPUT OPTIONS	9
2.11 Menu 16 - POWER ON DELAY	10
2.12 Menu 17 & 20 - OFF TO ON DELAY1 & OFF TO ON 2 DELAY2	10
2.13 Menu 18 & 21 - ON TO OFF DELAY1 & ON TO OFF DELAY2	11
2.14 Menu 19 & 22 - ON DELAY1 & ON DELAY2	11
<b>3. RE-CONFIGURING THE INPUT AND OUTPUT</b>	<b>12</b>
3.1 Set Voltage Input:	13
3.2 Set Current Input	14
<b>4. INSTALLATION NOTES</b>	<b>15</b>
<b>5. TROUBLESHOOTING</b>	<b>16</b>
5.1 Signal Pick-up	16
5.2 Ground Loops	16
5.3 HS-510 Error Messages	16
<b>6. HS-510 SPECIFICATIONS (@ 25°C)</b>	<b>17</b>
<b>7. WARRANTY</b>	<b>18</b>

## **1. QUICK START GUIDE**

The HS-510TL Dual Trip Amplifier is set at the factory to provide a fail-safe temperature monitor with digital display and two alarm levels. The HS-510TL is for use with an HS100T or HS-420T vibration and temperature sensors, or other device which uses the LM35 10mV/°C temperature sensor. Connections and default settings are shown on the drawings overleaf.

### **1.1 Display**

The HS-510TL display is set to indicate temperature in the range 0 to 100°C.

### **1.2 Relays & LEDs**

Alarm relays are set to be powered-on in the non-alarm condition for fail-safe operation. The LEDs will indicate an alarm condition.

### **1.3 Alarm Levels Settings**

The alarm level for RL1 (SP1) has been set at 50.0 and for RL2 (SP2) at 80.0 The alarm levels can be easily changed on installation by using the front panel 'raise' and 'lower' buttons as follows:-

- (a) Depress and hold both 'raise' and 'lower' buttons together for at least 2 seconds until 'OK' is displayed.**
- (b) Select '1.SETPOINT1' or '2.SETPOINT2' on the display using either button.**
- (c) Press and release both buttons quickly to display the current setting.**
- (d) Adjust the setting using the 'raise' or 'lower' button.**
- (e) Depress and release both buttons quickly to return to the SETPOINT menu.**
- (f) Depress and hold both buttons for at least 2 seconds until 'OK' is displayed to return to the run mode.**

For changes to all other HS-510 settings it is necessary to enter the Main Menu using a sequence of button presses. Refer to section 2.2 of this manual for details.

### **1.4 Alarm Delays**

To allow for excess vibration on start-up, a power on delay is set to 30 seconds, during which no alarms will operate. In addition both alarms are set with a 5 second delay such that the alarm conditions must be present for at least this time before the alarms operate.

### **1.5 Alarm Latching**


Both alarms are set to latch on operation and can be reset by depressing and releasing the 'Raise' and 'Lower' buttons together quickly.


### **1.6 Re-Transmit Output**

An isolated 4-20mA output for remote monitoring is available with connections as shown on the drawing overleaf.

### **1.7 Sensor Connection**

To avoid 50Hz pick-up and false display readings, the case of the sensor should be connected to its power supply 0V. ie connect the screen wire to the black wire as shown in the drawing overleaf.





## 2. RE-CONFIGURING THE HS-510

### 2.1 Set Point Menu

To access the set point menu push and hold both buttons until OK is displayed. Use the 'raise' and 'lower' buttons to cycle through:

1. SETPOINT 1 (Default 5.0)
2. SETPOINT 2 (Default 10.0)

To enter the setting mode depress and release both buttons quickly, then adjust the displayed setting using the 'raise' or 'lower' button. To return to the Set Point menu depress and release both buttons quickly. To return to the Run Mode depress and hold both buttons for 2 seconds until 'OK' is displayed.

### 2.2 Main Menu

To access the main menu the following sequence of button presses must be performed.

**Push and hold in both buttons then:  
release 'raise', hold in both,  
release 'lower', hold in both,  
release 'lower', hold in both,  
release 'raise', release lower**

This sequence must be performed correctly and within 10 seconds so a little practice and patience may be required. Successful entry to the main menu is indicated when setting options 1 to 22 can be scrolled through using the 'Raise' & 'Lower' buttons.

These are the main menu options, use raise and lower buttons to cycle through:

- |                |           |                         |            |
|----------------|-----------|-------------------------|------------|
| 1. SETPOINT 1  | (sec 2.1) | 12. INPUT ZERO          | (sec 2.8)  |
| 2. SETPOINT 2  | (sec 2.1) | 13. HYS 1               | (sec 2.9)  |
| 3. RELAY 1     | (sec 2.3) | 14. HYS 2               | (sec 2.9)  |
| 4. RELAY 2     | (sec 2.3) | 15. OUTPUT OPTIONS      | (sec 2.10) |
| 5. LED 1       | (sec 2.4) | 16. POWER ON DELAY      | (sec 2.11) |
| 6. LED 2       | (sec 2.4) | 17. OFF TO ON 1 (delay) | (sec 2.12) |
| 7. OUTPUT SPAN | (sec 2.5) | 18. ON TO OFF 1 (delay) | (sec 2.13) |
| 8. OUTPUT ZERO | (sec 2.5) | 19. ON DELAY 1          | (sec 2.14) |
| 9. INPUT UNITS | (sec 2.6) | 20. OFF TO ON 2 (delay) | (sec 2.13) |
| 10. RELAY TEST | (sec 2.7) | 21. ON TO OFF 2 (delay) | (sec 2.13) |
| 11. INPUT SPAN | (sec 2.8) | 22. ON DELAY 2          | (sec 2.14) |

To access the sub menu of one of the main menu options, use raise or lower to cycle to the option required then push and release both buttons quickly. Change the parameter as required using the raise or lower buttons. To return to the main menu, push and release both buttons quickly.

## 2.2 Main Menu Cont.

To exit from the main menu and return to run mode, press and hold both buttons for 2 seconds until OK is displayed on the screen.

After two minutes of inactivity from the front buttons when the main menu (or a sub menu) had been accessed, a timeout will occur and the unit will automatically return to run mode.

In run mode, briefly pressing and releasing both buttons will scroll the input value across the display with the units. Any latched relays will also be reset.

The following sections detail the main menu functions 3 to 22.


## 2.3 Menu 3 & 4 - RELAY1 & RELAY2


Each relay can function in one of the following:-

RLY 1 ON ABOVE SP1	RLY 2 ON ABOVE SP2
RLY 1 OFF ABOVE SP1	RLY 2 OFF ABOVE SP2
RLY 1 ON BELOW SP1	RLY 2 OFF ABOVE SP2
RLY 1 OFF BELOW SP1	RLY 2 OFF BELOW SP2
RLY 1 LATCH ON ABOVE SP1	RLY 2 LATCH ON ABOVE SP2
RLY 1 LATCH OFF ABOVE SP1 (Default)	RLY 2 LATCH OFF ABOVE SP2 (Default)
RLY 1 LATCH ON BELOW SP1	RLY 2 LATCH ON BELOW SP2
RLY 1 LATCH OFF BELOW SP1	RLY 2 LATCH OFF BELOW SP2

Latched relays are reset by pushing & releasing both buttons together in run mode.

Non-latched relays will reset when the alarm level falls below the level set by the HYS1 and HYS2 menu items 13 and 14 for the respective relays (see section 2.9). The following two drawings show the interaction of relay and hysteresis settings





**2.4 Menu 5 & 6 - LED 1 & LED 2**

The LEDs on the front panel can be configured in the following ways:

- LED 1 ON WHEN RLY 1 ON
- LED 1 ON WHEN RLY 1 OFF *(Default)*
- LED 2 ON WHEN RLY 2 ON
- LED 2 ON WHEN RLY 2 OFF *(Default)*

**2.5 Menu 7 & 8 – OUTPUT SPAN & OUTPUT ZERO**

Setting of the zero and span points is non-interactive, so each point need only be set once. *(Default Zero: 4mA, Default Span: 20mA)*. Re-calibration of the output zero and span is performed using a digital multi-meter (DMM) connected to the output terminals. A typical calibration sequence would be as follows:

Display	Action
7.OUTPUT SPAN	Apply full scale input. Press and release both buttons together
SPAN ADJUST	Press raise/lower buttons to adjust output on DMM until correct Press and release both buttons together
7.OUTPUT SPAN	Press raise button to change main menu item to 8.OUTPUT ZERO
8.OUTPUT ZERO	Apply zero scale input Press and release both buttons together
ZERO ADJUST	Press raise/lower buttons to adjust output on DMM until correct Press and release both buttons together

## 2.6 Menu 9 – INPUT UNITS

The following units are available to represent the input signal.

**%, mA, V, A, mV, °C, OHM, blank** (Default: Blank 2DP)

The number of decimal places can be chosen, for each selected unit, to allow a bigger input range (with lower resolution) to be represented.

2 decimal places (-327.68 to 327.67) or 1 decimal place (-3276.8 to 3276.7)

## 2.7 Menu 10 – RELAY TEST

This option allows the relays and LEDs to be tested.

RLY 1 OFF RLY 2 OFF (both LEDs off)

RLY 1 OFF RLY 2 ON (just LED2 on)

RLY 1 ON RLY 2 OFF (just LED1 on)

RLY 1 ON RLY 2 ON (both LED on)

Note that the unit will automatically timeout after two minutes of inactivity from the front buttons, and return to run mode.

## 2.8 Menu 11 & 12 – INPUT SPAN & INPUT ZERO

(Default Input Span = 20.00mA, Default Input Zero = 4.00mA).

In run mode the front panel display shows the value of the input to the HS-510. Values can be adjusted to correspond to the full scale and zero scale input values used when Output Span and Output Zero were adjusted.

## 2.9 Menu 13 & 14 - HYS1 & HYS2

(Default: 0.20)

This sets the level at which non-latched relays will reset when the vibration level falls below the alarm level. The default hysteresis is set at 0.2 which means that for an alarm level set for 'above' 10 the relay reset level is at 9.8 as shown in section 2.3.

## 2.10 Menu 15 – OUTPUT OPTIONS

Averaging and burnout options can be selected. To restore the default values, choose DEFAULT VALUES then press and release both buttons to return to the main menu. From that point on, all values will have returned to defaults.

AVERAGE ON HIGH BURNOUT (Default)

AVERAGE ON LOW BURNOUT

AVERAGE OFF HIGH BURNOUT

AVERAGE OFF LOW BURNOUT

DEFAULT VALUES

**2.10 Cont.**

High burnout values are approximately 23mA or 11.5V.  
 Low burnout values are approximately 0mA or 0V.

Averaging is carried out using the following algorithm (a weighted average of the last eight readings, with each new reading every 20 milliseconds):


$$\text{New Average} = \frac{\text{New Reading} + (7 \times \text{Old Average})}{8}$$

**2.11 Menu 16 – POWER ON DELAY**

After power on, relays cannot trip during this time delay. *(Default 30 seconds)*  
 There are seven time delays available. The maximum values are 1310.7 seconds, with a resolution of 20 milliseconds.


**2.12 Menu 17 & 20 - OFF TO ON DELAY1& OFF TO ON 2 DELAY2**

The trip condition must be seen for this delay before the relay can trip (see picture below). *(Default 5.0 seconds)*




**2.13 Menu 18 & 21 - ON TO OFF DELAY1 & ON TO OFF DELAY2**

The trip condition must not be seen for this delay before the relay can reset (see pictures below). (*Default 0.5 seconds*)




**2.14 Menu 19 & 22 - ON DELAY1 & ON DELAY2**

Relay must remain tripped for this delay before being allowed to reset (see picture below). (*Default 0.5 seconds*)



2.14 MENU 19 & 21 Cont.

All 3 delays (or any combination) can be used at the same time if desired. Note that if the relay is tripped, both the 'on delay' timer and the 'on to off delay' timer can hold the relay in the tripped condition until both have expired (see picture below).



3. RE-CONFIGURING THE INPUT AND OUTPUT




**! WARNING !**  
**DO NOT OPEN UNIT OR ADJUST SWITCHES WITH**  
**POWER SUPPLY, INPUT OR OUTPUT CONNECTED**

To change the input output setting from the default 4-20mA it is necessary to remove the HS-510 from its outer case. To open the HS-510, 2 catches just below the outer terminal blocks must be pushed in gently, one at a time. The front of the case can then be pulled and the unit will withdraw from the cover.



Press here gently

There are 2 switch banks, S1 and S2, a link L201 and a single switch S3 located inside the HS-510 as shown below:-



Switch S1, S2 and Link L201 configure the input type and range, and switch S3 configures the output type. Link L201 is connected only for potentiometer inputs which are not considered in this manual. The switch settings are explained in the next few pages. The diagrams refer to switch positions 0 and 1, with 0 being OFF and 1 being ON. This is illustrated in the picture above.

### 3.1 Set Voltage Input:

Select the range from the table below and set Switch S1 to the required values.

Voltage Range	Switch S1											
	1	2	3	4	5	6	7	8	9	10	11	12
<b>0-1V</b>	0	0	0	0	0	1	0	0	1	1	0	0
0-2V	0	0	0	1	}							0
0-4V	0	0	1	0								0
<b>0-5V</b>	0	1	0	0								0
0-7.5V	1	0	0	0								0
0-8V	0	0	1	1								0
<b>0-10V</b>	0	1	0	1								0
0-15V	1	0	0	1								0
0-20V	0	1	1	0								0
0-30V	1	0	1	0								0
0-40V	0	1	1	1								0
<b>1-5V</b>	0	1	0	0								1
-5 to +5V	1	1	0	0								1
<b>-10 to +10V</b>	1	1	0	1	0	1	0	0	1	1	0	0

Then select the required setting from the table below for switch S2.

Voltage Range	Switch S2											
	1	2	3	4	5	6	7	8	9	10	11	12
0-30V & 0-40V Ranges	0	0	1	1	0	0	1	1	0	0	0	0
All other Ranges Listed Above	0	0	1	0	1	0	1	0	0	0	0	0

### 3.2 Set Current Input

Select the range from the table below and set Switch S1 to the required values.

mA Range	Switch S1											
	1	2	3	4	5	6	7	8	9	10	11	12
<b>0-1mA</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>0</b>
0-2mA	0	0	0	1	}							0
0-4mA	0	0	1	0								0
0-5mA	0	1	0	0								0
0-8mA	0	0	1	1								0
0-10mA	0	1	0	1	↓							0
0-15mA	1	0	0	1								0
<b>0-20mA</b>	<b>0</b>	<b>1</b>	<b>1</b>	<b>0</b>	↓							<b>0</b>
0-30mA	1	0	1	0								0
<b>4-20mA</b>	<b>0</b>	<b>1</b>	<b>1</b>	<b>0</b>	↓							<b>1</b>
4-40mA	0	1	1	1								1
4-30mA	1	0	1	0	↓							1
-5 to +5mA	1	1	0	0								0
-10 to +10mA	1	1	0	1	0	0	0	0	1	1	1	0

**Set Current Input Cont.** Then select the required setting from the table below for switch S2.

mA Range	Switch S2											
	1	2	3	4	5	6	7	8	9	10	11	12
Using Internal 24V Tx Supply for 4 to 20mA transmitter	1	1	0	1	0	0	1	1	0	0	1	0
Unipolar Ranges (e.g. 0-20mA, 4-20mA)	1	1	0	0	0	0	1	1	0	0	0	0
Bipolar Ranges (e.g. -10 to +10mA)	1	1	0	0	1	0	1	0	0	0	0	0



**! WARNING !**  
**DO NOT OPEN UNIT OR ADJUST SWITCHES WITH POWER SUPPLY, INPUT OR OUTPUT CONNECTED**

#### 4. INSTALLATION NOTES

The HS-510's input and output circuits are classed as Separated Extra Low Voltage (SELV). This means that they must not be externally connected to voltages exceeding 30V ac or 60V dc, nor do they generate voltages above these limits internally. Where a higher voltage input is required a specially designed voltage divider unit should be used to condition the input signal prior to connection to the process input terminals.

The HS-510 unit clips directly onto 'Top Hat' (TS35) symmetrical DIN rail. Ideally, mounting orientation should be vertical. Good airflow around the unit will maximise reliability of the instrument.

The use of bootlace ferrules is recommended on wiring terminations.

Do not exceed terminal torque rating of 0.4 Nm – use an appropriate screwdriver. The unit can be removed from the DIN rail by sliding a small screwdriver into the slot at the rear of the enclosure on the lower face and gently levering the metal clip, whilst lifting the unit from the rail.

## 5. TROUBLESHOOTING

### 5.1 Acceleration Signal Pick-up

In many industrial environments, the low amplitude signals generated by an accelerometer can be corrupted by pick-up from nearby electric fields produced by motors, generators or speed control electronics. This can result in higher than expected vibration readings. In the HS-100 series accelerometers the effect is minimised by an internal 'Faraday shield' which is connected to the signal 0V but isolated from the outer case. In extreme circumstances, however, careful shielding and grounding arrangements may be necessary. To avoid signal pick-up, the requirement is that the accelerometer outer case should be connected via a continuous cable screen to the 0V of the power supply that provides the accelerometer power. This will prevent coupling of spurious signals on the accelerometer case and wiring into the measurement circuit. In many applications this can be easily achieved by connecting the accelerometer screen wire to the black wire at the module terminals.

### 5.2 Ground Loops

Ground loop problems occur when shielding conductors are grounded at physically different points. Large circulating currents in the loop can be created by changing magnetic fields within the loop. This causes potential differences, usually at 50Hz, at the supposedly grounded points which add to the vibration signal, resulting in incorrect readings. Ground loop effects can be avoided by grounding either the accelerometer body or the power supply 0V, but not both. Where a machine casing is electrically 'noisy', it may be necessary to use an isolating mounting stud. In HS-100 accelerometers the outer case can then be connected to the measurement 0V via the screen wire. It is rarely possible to predict the optimum grounding configuration for a vibration measuring system and this will need to be established empirically on installation.

### 5.3 HS-510 Error Messages

The HS-510 has some built in self diagnostic functions. Errors encountered will be displayed on screen.

**BURNOUT ERROR**                      Refers only to RTD or Thermocouple inputs.

**EEPROM ERROR**    Stored data has been corrupted. Push and release both buttons then recalibrate the output and reset all the required options and values.

<p><b>NO DATA ERROR</b>  <b>PARITY ERROR</b>  <b>ADC ERROR</b>  <b>CJC ERROR</b></p>	}	<p>Switch off unit, check switch settings and wiring, then re-try. If still faulty please contact supplier.</p>
--	---	---

**6. HS-510 SPECIFICATIONS (@ 25°C)**

Operating Temperature.....	0 to 55 °C
Operating Altitude .....	Sea Level to 2000m
Humidity.....	0-90% RH
Power Requirements.....	DC Supply 16 to 30VDC AC Supply 16 to 32VAC
Current Consumption .....	55mA @ 24VDC (20mA in & out) 90mA as above with both relays & LEDs on 85mA @ 24VDC (maximum load, TX supply) 120mA as above with both relays & LEDs on 260mA for 50ms on 24VDC power up
Transmitter Power Supply .....	22V to 29V @ up to 24mA dependant on supply voltage and load
Calibration accuracy .....	±0.05% full scale
Linearity.....	±0.05% full scale
Temperature Stability .....	50ppm / °C
Input Impedance: .....	Current Input 15Ω Voltage Input 1 MΩ
Millivolt Input.....	> 10MΩ
Maximum Voltage Output.....	11.5 V into a minimum of 7kΩ
Maximum Current Output .....	23.0 mA into a maximum of 1kΩ
Time Response (90% of step change): .....	50ms ± 10ms
Isolation .....	Full 3 port Isolation to1kV between Power Supply Input and Output.
Transient Withstand.....	2.5kV for 50 µsecs.
Dimensions .....	114.5 mm x 99mm x 22.5mm (H x D x W)
Mounting .....	DIN Rail TS35
Connections .....	Screw Clamp with pressure plate
Conductor Size .....	0.5 to 4.0 mm
Insulation Stripping .....	12 mm
Maximum Terminal Torque .....	0.4 Nm
Weight .....	Approx. 140g
EMC Emissions .....	EN50081-1:1992 EN50081-2:1993
EMC Immunity.....	EN50082-1:1997
LVD Standards .....	EN61010-1:1993
Installation Category.....	(IEC 664)II
Pollution Degree (EN61010-1:1993).....	2
Equipment Class (IEC 536).....	II
Mains Rated Relays.....	3A resistive at 240VAC

## 7. WARRANTY

All goods are guaranteed against defects in materials and workmanship, subject to specific exclusions, for a period of 36 months from the date of purchase. In the event of failure within 36 months of original purchase, the company will promptly repair or replace the defective components without charge.

Specific exceptions rendering the Warranty void are:-

If repair is attempted by unauthorised persons or agents, or if the product has been used for purposes for which it was not intended and or subjected to abuse or wilful neglect. No liability can be accepted for loss of items or component parts. It is expected that the user takes sufficient precautions to safeguard all guaranteed items.

Hansford Sensors Ltd,  
Artisan, Hillbottom Road  
Sands Industrial Estate, High Wycombe,  
Buckinghamshire, HP12 4HJ  
Tel: +44 (0)845 6801957, Fax: +44 (0)845 6801958  
[www.hansfordsensors.com](http://www.hansfordsensors.com)